

No.	Part	Material
1	Plug wire	
2	Tank	08F
3	Pressure switch	
4	Flexible hose	AISI 304
5	Plug	
6	Third pipe connection	H59
7	Pump body	HT200
8	Pressure gauge	
9	Nozzle	PPO
10	Vunteri tube	PPO
11	Diffuser	PPO
12	Nut	
13	Impeller	PPO
14	Mechanical seal	
15	O-ring	NBR
16	Support	HT200
17	Bolt	
18	Stator	
19	Terminal Box	
20	Bearing	
21	Capacitor	
22	Connection line	
23	Rotor	
24	Bolt	
25	Rear cover	HT200
26	Fan	PP
27	Fan cover	08F

